



Installation Guide

BHMXX



Tools Required:

- 12mm socket or spanner (or as applicable to factory bonnet bolts)
- Torque wrench (optional but recommended)
- Assistant

Important Notes:

- Use OEM bonnet bolts unless replacement hardware is provided.
- Do not install the bracket between the bonnet and hinge.
- Always check bonnet alignment after installation.

Step-by-Step Installation:

- 1. Preparation**

Park the vehicle on a level surface. Ensure the engine is off and the bonnet is cool to the touch. Have an assistant support the bonnet throughout the installation process to prevent misalignment or damage.
- 2. Remove Factory Bolts**

Open the bonnet fully. While the assistant holds the bonnet in the centre, remove the two bolts securing the bonnet to the hinge on the intended side.
- 3. Install Mounting Bracket**

Place the bracket on top of the bonnet hinge mounting point: not between the hinge and bonnet. Reinsert the bolts through the bracket and into the factory holes. Hand-tighten at this stage.
- 4. Align and Secure**

Using the original paint witness marks as a guide, carefully realign the bonnet hinge to its previous position. Once correctly aligned, fully tighten the bolts to the manufacturer's torque specification if available.
- 5. Final Check**

Slowly close the bonnet to verify proper alignment and latch engagement. Make any necessary adjustments before final use.
- 6. Aerial Installation**

Install aerial as per manufacturer's recommendations. Ensure cabling does not foul on the bonnet or hinge.

Disclaimers:

- This product is intended for use only on compatible vehicles. The purchaser is responsible for verifying suitability prior to installation.
- GME strongly recommends professional installation by a qualified technician. Damage resulting from improper fitment or handling is not covered by warranty.
- All fasteners must be installed to manufacturer-recommended torque settings. Failure to do so may result in product failure or vehicle damage.
- No modification to the product or mounting points is permitted. Any alteration voids the warranty and may compromise compliance with applicable vehicle regulations.
- Product must be inspected prior to installation. Do not install if any damage or manufacturing defect is present. Contact your authorised distributor for support.
- After installation, ensure all components are securely fastened and do not impede bonnet movement or line-of-sight. The bracket should be adjusted to ensure there is no contact with the edge of the bonnet when opened or closed.
- Fasteners should be re-checked after 500 km of use and periodically thereafter, particularly in off-road or high-vibration environments.
- GME accepts no responsibility for damage to vehicle components, loss, or injury resulting from installation errors, misuse, or unauthorised modification.
- Under no circumstances shall GME or its manufacturing partners be liable for indirect or consequential damage resulting from improper installation or use of this product.